



GENERAL®

DIGITAL FOUR CHANNEL TIMER/CLOCK

User's Guide



Magnets on back of product can attach to metal products



Press down the battery cover and slide to open

